



Ingenico Link/2500 Portable Terminal Set Up

Before you begin, it is recommended that the terminal be fully charged or plugged in to a power source.

- Power on the device
- Tap 0-0-0-1 to unlock
- To set up the Wifi, use the F2/F3 key to find "Wifi Parameters"
 - On the second menu, select "Scan Network"
 - Use the green button to select your network
 - Enter Wifi password
 - Password is case sensitive. Once entered correctly, the device will show "New Profile OK" and divert back to the main screen
 - The wifi symbol should now be green in the top left
- An activation code should populate on the screen
 - If you do not get an activation code:
 - If plugged in: Press and hold the # and Yellow keys, to reboot device
 - If unplugged: The device will power down, power the device back on by holding the green key

The terminal will need to be activated in the Back-Office before use. Please follow the instructions below to activate the terminal.

- Log into the Back-Office
- Go to "Terminal Management"
 - Main Menu > Admin > Accounting > Certellipay > Terminal Management
- Select the "Activate Terminal" plus icon
- Input the activation code from the terminal screen
- Select merchant
- Give the terminal a description
- Select "Activate"
- If successful, the terminal will appear on the terminal management page
- To update or add an additional merchant to the terminal select the edit icon
 - Each merchant must have their own description
 - Merchants can be easily deactivated by selecting "Deactivate"

Tips

- The keypad uses multi-tap entry, pressing the "2" button repeatedly will go through the number "2" and the letters "a, b and c" in both lower and upper case
 - To enter a symbol, press the symbol button (.,#*)
 - To erase, press the yellow button
- The following keys are used for navigation:
 - (F1) - Scrolls the selection to the left
 - (F2) - Scrolls the selection up
 - (F3) - Scrolls the selection down
 - (F4) - Scrolls the selection to the right
- To go back to a previous screen, press the red button
- The device should turn on automatically when connected to a power source
- Power down the device by holding the symbol (.,#*) and the yellow buttons simultaneously